

ADJUSTING AGITATOR & WATER PUMP PRESSURE



Detachable Placing Boom Model Shown

TOOLS REQUIRED

1. 3MM Allen Key Wrench:
2. 14MM Open End Wrench:
3. High Pressure 400 Bar Gauge:



PROCEDURES

1. Install the high pressure 400 bar gauge to the "Pressure Gauge Port" located on the "Agitator Valve Bank":
2. Loosen the 14 mm "Lock Nut":
3. Activate the water pump lever to the none working, "Pressure On" position:
4. Note: To increase "Circuit Pressure" turn Allen Key Wrench in, "Clockwise":
5. To reduce " Circuit Pressure" adjust Allen Key Wrench out, "Counter Clockwise":
6. Using a 3mm "Allen Key Wrench" adjust "Water Pump & Agitator" Circuit Pressure to 170 Bar, (2,400 PSI):
7. Tighten the 14mm "Lock Nut":
8. If you have questions regarding this procedure please call the Concord Service Department or Customer Support Team at 1.888.201.2223 or locally call 1.604.468.7867.